



1080P INDOOR+ OUTDOOR WI-FI VIDEO CAMERA

INSTALLATION GUIDE
ADC-V722W



Pre-Installation Checklist

- ADC-V722W camera (included)
- AC Power adapter (included)
- Wireless (2.4 or 5 GHz) connection to broadband (Cable, DSL, or Fiber Optic) Internet
- A computer, tablet, or smartphone with Wi-Fi is required if the router does not have the Wi-Fi Protected Setup (WPS) feature
- Login and Password for the Alarm.com account to which you will add the camera

Note: There are two options for connecting the ADC-V722W to the wireless network: Wi-Fi Protected Setup (WPS) Mode, and Access Point (AP) Mode.

WPS Mode

Add the Camera to an Alarm.com Account

To ensure sufficient Wi-Fi signal, complete these steps with the camera near its final location but prior to mounting.

- 1 Connect the camera's AC power adapter and plug it into a non-switched outlet.
- 2 Hold down the WPS button and release when the LED begins to flash blue (about 3 seconds).
- 3 Activate the WPS Mode on the router. The router will begin to connect to the wireless network. The LED will be solid green when the connection is complete.
- 4 Add the device to the account by either selecting the account in MobileTech OR by using a web browser and entering the following URL: www.alarm.com/addcamera
- 5 Select the camera from the video device list or type in its MAC address to begin adding the camera. The camera's MAC address is located on the back of the camera.
- 6 Follow the on-screen instructions to finish adding the camera. You may configure camera settings from the Customer Website.

You can now power down the camera and install it in its final location using the included hardware.

AP Mode

Add the Camera to an Alarm.com Account

To ensure sufficient Wi-Fi signal, complete these steps with the camera near its final location but prior to mounting.

- 1 Connect the camera's AC power adapter and plug it into a non-switched outlet.
- 2 Hold down the WPS button and release when the LED begins to flash white (about 6 seconds).
- 3 On an Internet enabled device, connect to the wireless network "ALARM (XX:XX:XX)" where XX:XX:XX is the last six digits of the ADC-V722W's MAC address, which is located on the back of the ADC-V722W.
- 4 On the same device, open a web browser and enter "http://722winstall" in the URL field. Follow the on-screen instructions to add the ADC-V722W to the wireless network. The LED will be solid green when the connection is complete.
- 5 Add the device to the account by either selecting the account in MobileTech OR by using a web browser and entering the following URL: www.alarm.com/addcamera
- 6 Select the camera from the video device list or type in its MAC address to begin adding the camera. The camera's MAC address is located on the back of the camera.
- 7 Follow the on-screen instructions to finish adding the camera. You may configure camera settings from the Customer Website.

You can now power down the camera and install it in its final location using the included hardware.

LED Reference Guide

Status

Solid Green | Internet connection



Local network and internet connection

Flashing Green | Local network connection



Local network connection only, no internet

Solid Red | No network connection



No local network or internet connection

Flashing Red | System booting



Camera is booting

Wireless Enrollment

Flashing Blue | WPS Mode



To enter WPS mode, push the WPS button and release when flashing blue (about 3 seconds). **See instructions above to add the camera to your router and account using WPS.**

Flashing White | AP Mode



To enter AP mode, push the WPS button and release when flashing white (about 6 seconds). **See instructions above to add the camera to your router and account using AP mode.**

Factory Reset

Flashing Green & Red | Factory Reset



WARNING: This will restore factory-default settings to the camera. If already installed, the camera may need to be removed from the Alarm.com account and re-added after a factory reset. **To perform a factory reset, push the WPS button and release when flashing Green and Red (about 15 seconds).**

Troubleshooting

- If you have issues connecting the camera to the account, power cycle the camera and try again.
- If issues persist, reset the camera to factory defaults by using the WPS button located on the back of the camera. Press and hold the WPS button until the LED is flashing Green and Red (about 15 seconds), then release the button. The camera will reboot with factory defaults. If the camera was previously installed to an Alarm.com account, it will need to be deleted before it can be installed again.

Questions?

Visit: www.alarm.com/supportcenter





ALARM.COM®